



Anchor Kit Installation Guide

Oz Trampolines newly designed anchor kits are designed to keep your trampoline grounded.

Installation will take 5 minutes and you will need a hammer.



Parts

Each anchor kit consists of a high quality steel peg and a leg clamp.



Step 1

Place the peg next to the middle of the trampoline leg, and then either screw or hammer the peg into the ground until the loop at the top is level with the raised part of the leg.

Handy Hint

Make sure to wet the ground if it's dry. This will help when you need to put the peg in the ground.

Step 2

Take the leg clamp and place it around the leg, then place the clamp through the peg and tighten.

Please Note

These clamps are designed to be compatible with Oz Trampolines models, as the trampoline legs are screwed together and connected to the trampoline frame. Some trampoline brands do not use screws to keep the trampoline together and this anchor kit would not be suitable.